

## ■パナソニック製エアコン スマートスピーカー連携サービス非対応機種

エアコン	Xシリーズ	・CS-X223C-W 　・CS-X223C-C 　・CS-X253C-W 　・CS-X253C-C 　・CS-X283C-W 　・CS-X283C-C 　・CS-X283C2-W ・CS-X283C2-C 　・CS-X363C-W 　・CS-X363C-C 　・CS-X363C2-W 　・CS-X363C2-C 　・CS-X403C-W 　・CS-X403C-C ・CS-X403C2-W 　・CS-X403C2-C 　・CS-X563C2-W 　・CS-X563C2-C 　・CS-X633C2-W 　・CS-X633C2-C 　・CS-X713C2-W ・CS-X713C2-C 　・CS-223CXR-W 　・CS-253CXR-W 　・CS-283CXR-W 　・CS-363CXR-W 　・CS-403CXR-W 　・CS-403CXR2-W ・CS-563CXR2-W 　・CS-223CX-W 　・CS-223CX-C 　・CS-253CX-W 　・CS-253CX-C 　・CS-283CX-W 　・CS-283CX-C ・CS-283CX2-W 　・CS-283CX2-C 　・CS-363CX-W 　・CS-363CX-C 　・CS-363CX2-W 　・CS-363CX2-C 　・CS-403CX-W ・CS-403CX-C 　・CS-403CX2-W 　・CS-403CX2-C 　・CS-563CX2-W 　・CS-563CX2-C 　・CS-633CX2-W 　・CS-633CX2-C ・CS-713CX2-W 　・CS-713CX2-C 　・CS-633CXR2-W 　・CS-713CXR2-W
	UXシリーズ	・CS-UX253C2-W 　・CS-UX283C2-W 　・CS-UX403C2-W 　・CS-UX563C2-W
	SXシリーズ	・CS-SX223C-W 　・CS-SX253C-W 　・CS-SX283C-W 　・CS-SX363C-W 　・CS-SX403C2-W 　・CS-SX563C2-W 　・CS-223CSX-W ・CS-253CSX-W 　・CS-283CSX-W 　・CS-363CSX-W 　・CS-403CSX2-W 　・CS-563CSX2-W
	Tシリーズ <small>室内の湿度は表示されません。</small>	・CS-T223C-W 　・CS-T223C-C 　・CS-T253C-W 　・CS-T253C-C 　・CS-T283C-W 　・CS-T283C-C 　・CS-T283C2-W ・CS-T283C2-C 　・CS-T363C2-W 　・CS-T363C2-C 　・CS-T403C2-W 　・CS-T403C2-C 　・CS-223CT-W 　・CS-223CT-C ・CS-253CT-W 　・CS-253CT-C 　・CS-283CT-W 　・CS-283CT-C 　・CS-283CT2-W 　・CS-283CT2-C 　・CS-363CT2-W ・CS-363CT2-C 　・CS-403CT2-W 　・CS-403CT2-C 　・CS-T563C2-W 　・CS-T563C2-C 　・CS-563CT2-W 　・CS-563CT2-C
	Aシリーズ	・CS-22PAE1-W 　・CS-25PAE1-W 　・CS-28PAE1-W 　・CS-36PAE1-W 　・CS-40PA2E1-W 　・CS-56PA2E1-W 　・CS-63PA2E1-W ・CS-71PA2E1-W